

## Klebstoffempfehlung für The Floor Dryback

<b>Thomsit-Klebstoffe</b>	<b>K 190 F</b> <b>K 188 S</b> <b>K 188 E</b> <b>K 195</b> <b>R 710</b>
<b>UZIN</b>	<b>UZIN KE 2000 S</b> <b>UZIN KE 66</b> <b>UZIN KE 68</b>
<b>WAKOL</b>	<b>WAKOL D 3307</b> <b>WAKOL D 3317</b> <b>WAKOL D 3318</b> <b>WAKOL D 3319</b> <b>WAKOL D 3320</b> <b>WAKOL D 3360</b> <b>WAKOL MS 550</b> <b>WAKOL MS 552</b> <b>WAKOL PU 270</b>
<b>Mapei</b>	<b>ULTRABOND ECO 4 LVT</b> <b>ULTRABOND ECO V4 SP</b>
<b>Bostik</b>	<b>Bostik Stix A540 Multi Plus</b> <b>Bostik Stix A550 PowerElastic</b> <b>Bostik Stix A900 Resist+</b>

**Immer die Angaben des Klebstoffherstellers beachten.**